

# F5 Series Electronic Password Instruction Manual

## Warnings:

1. Do not lock the emergency key or external battery box into the cabinet.
2. If the safe box is not used for a long time, please remove its battery.
3. Purchase 4 AA batteries in advance, this safe does not contain batteries.
4. Factory default password: 123456.

## How to use your safe box?

### ➤ **Step1 Open the safe for the first time**

Left slide the keyhole cover to expose the emergency keyhole, insert the emergency key, Turn the key to the limit position. turn the knob clockwise to open the door successfully for the first time.

### ➤ **Step2 Insert the battery**

Remove the internal battery box cover and install the 4 AA 1.5 Volt alkaline batteries, the system will power on (rechargeable battery is not recommended as it may destroy safe box' s internal electronic components)

### ➤ **Step3 Set the password**

#### **The first set of password settings:**

Short press the setting button, the cursor flashes on the panel enter a 4-8 digits new password on the panel, press # to confirm, the password is set successfully.

#### **2. Admin Password Settings:**

Open the door, press the # key to wake up the screen, enter "00", press the setting key button in the door, enter the required administrator password as numbers from 4 to 8, and press the # key to confirm. The message "INTO" is set successfully. After the password is set, verify it and lock the door after confirmation.

**Tip: Please verify the passwords after done the passwords setting, and lock the door after verification.**

#### **Error alarm function**

After 3 consecutive time of wrong code, your safe will activate the alarm system, the alarm will sound, then enter the correct password and the alarm will be cancelled.

#### **Vibration alarm mode setting**

In the standby state, press the "0" key, that is, successfully enter the alarm state. At this time, when the box is shaken by the outside world, the alarm is immediately reported, and the correct password can be lifted by pressing the # key to confirm.

### **How to open the inner cabinet door**

Insert the key into the inner door of the cabinet, turn the key to the limit and pull it outward to open the inner door of the cabinet.

### **How to use emergency battery box**

When the safe box ' s battery is too low to open the door, insert 4AA 1.5 batteries in the emergency battery box, plug the emergency power cord into the emergency power jack on the bottom edge of the panel, then enter the correct password to open the door.

### **How to mount the safe?**

1. Place the safe on the installation location, find the installation holes from the inside of the safe, mark the drilling points from the inner installation holes, then remove the safe and drill two holes.
2. Take the expansion bolt out of the casing and put it into the drilled hole, then align the pre-drilled hole with the inner hole of the safe, and then insert the expansion bolt into the casing from the inside of the safe.